



Installation Instructions

Front net for Jeep JK unlimited
2007-2011
DD-N-JK4-07F
J4NN07F1**

-Thank you for purchasing a Dirtydog 4x4 netting system. Please read these instructions fully to familiarize yourself with the installation. Set aside 15 minutes for the first time you install your net. Installation is done easiest with the hard top removed and the soft top is open.

Start with the right or left side. The front side of the net has no loops on it. This side runs along the front windshield. Install four straps down one side. Install them very loosely until you get the other side on. The most forward straps slide under the trim piece. See close up below. Do this on both sides. Snug up the straps equally on both sides.



The next step is the rear corners. You need to take the long straps and feed them in between the roll bar and the sound bar. You may need to loosen of the sound bar bolts temporarily so you can push the strap through. These bolts are found on the underside of the sound bar. Pull it through the bottom and up around the outside of the roll bar and connect to the ladderloc on the top again. Do this on both sides. Go around and adjust the net so the piece is centered on top.



Connect the center loops through the sound bar and around the middle section loops.



The final will be to install the shock cords around the footman loops at the top of the windshield as shown



Adjust and tighten straps as needed to even out the net so it is positioned properly.

Your net comes with a 3 year warranty against manufacturing defects. Cuts, abrasions, sun faded items are not covered under the warranty.



Dirtydog 4x4
Mississauga, ON
Canada
855-704-0708
Question? Call or email orderdesk@dirtydog4x4.com